

POLISH GRIP

TECHNICAL DATA SHEET

[CLICK TO LEARN MORE →](#)

SlipDoctors Polish Grip is a professional-grade penetrating sealer designed to provide anti-slip protection on unsealed natural stone, polished porcelain tile, marble, granite, concrete and other surfaces. This easy-to-apply treatment forms an invisible barrier that increases traction and improves resistance to spills and stains. Once applied, the lustrous natural shine remains unchanged. For use on interior and exterior surfaces.

Special Features

- Use on Interior & Exterior Surfaces
- Water, Stain & Slip Protection
- Increases the Coefficient of Friction
- Weather Resistant
- One product = Multiple uses
- Retains Natural Color and Shine
- Easy to Apply
- Safe in Food Areas

Suggested Uses

- Residential & Commercial Use
- Hotels, Motels & Resorts
- Senior Living Facilities
- Restaurants
- Kitchens & Bathrooms
- Tiled Swimming Pool Decks
- Patios
- Highly Polished Stone Surfaces

Product Characteristics and Benefits

Surfaces	Granite, marble, natural stone, porcelain tile, concrete, ceramic tile, slate, limestone, grout, terrazzo, travertine, glazed tile and quarry tile.
Color	Clear
Mode of Application	Clean white towel, microfiber towel, paint roller/brush or Polish Grip Applicator.
Container Size	Pint and Gallon
Application Temperature	Surface temperature above freezing.
Dry to Touch	Immediately after treatment
Light Traffic	4-6 hours
Cure Time	up to 72 hours
Recoat	1 hour
Water Resistant	Yes
Stain Resistant	Yes
Product Type	Penetrating Sealer
Coverage	Up to 300 sq.ft./pint and up to 2,400 sq.ft./gallon
Storage	Store tightly sealed in original container at room temperature of 78°F (25°C)
Shelf Life	1 year
Treatment Life	3-12 months, depending on type of surface and amount of foot traffic.
Warranty	1 year
Removal	N/A



Precautions & Technical Support

Please refer to Safety Data Sheet (SDS) for detailed Precautions and First Aid Instructions. Polish Grip Safety Data Sheet can be found at www.slipdoctors.com

Technical Support:

Please contact SlipDoctors at support@slipdoctors.com



Product Characteristics and Benefits

Disposal

Dispose of container and unused contents in accordance with local, state, and federal regulations.

Directions for Preparation, Application and Use

Read entire product label, Technical Data Sheet (TDS) & Safety Data Sheet (SDS) before using.

Surface Preparation

- Clean surface thoroughly with pH neutral cleaner.
- Surface must be clean and dry before application.
- Do not apply if it has rained in the last few days or if humidity level is high.
- Protect exposed surfaces including wood, carpet, metal and landscaping.

Installation Application Instructions

Step 1: Read label thoroughly before application.

Step 2: SAMPLE TEST: Due to variations in substrates, perform a sample test to ensure maximum performance and suitability for the intended use. Test product in an inconspicuous area and allow to fully cure to test results.

Step 3: Do not thin or dilute. Apply Polish Grip evenly to surface until damp using a clean white towel, microfiber towel or Polish Grip Applicator. Leave on surface for 3 to 5 minutes for maximum penetration.

Step 4: Remove all excess product using a new clean white towel, microfiber towel or carpet bonnet before product dries.

Step 5: Any excess residue that dries on the surface can be removed by re-applying a small amount of Polish Grip and immediately wiping off excess while wet.

Step 6: If a second application is desired, wait at least 1 hour before applying.

Step 7: Polish Grip will fully cure in 24-72 hours, depending on conditions.



Warranty & Disclaimer

WARRANTY: All properly installed SlipDoctors products are guaranteed to increase the coefficient of friction of your surface for two (2) years (provided surface preparation and cleaning procedures are followed and no contaminants are present). If at any time during the warranty period the treated surface should lose its coefficient of friction, SlipDoctors shall at its option replace any product that proves defective. This warranty applies only to the product itself. Neither the Seller nor the Manufacturer shall be liable for any injury, loss or damage direct or consequential, arising out of the use or the inability to use the product. Before using, Buyer shall determine the suitability of the product for the intended use, and the Buyer assumes all risk and liability whatsoever in connection therewith. No statement or recommendation not contained herein shall have any force or effect unless in an agreement signed by Seller and Buyer. Buyer assumes all risks and responsibility associated with disposal. SlipDoctors cannot eliminate all possibilities of slip-and-fall accidents. Please visit www.slipdoctors.com to find further warranty information. KEEP OUT OF REACH OF CHILDREN.

