

TUB GRIP

TECHNICAL DATA SHEET

[CLICK TO LEARN MORE →](#)

SlipDoctors® TUB GRIP is a non-yellowing, water-based epoxy/acrylic coating designed to provide anti-slip protection on bathtubs and showers. Tub Grip is durable, chemical resistant and provides effective anti-slip protection. Tub Grip provides a glossy finish to enhance the natural appearance of your tub or shower.

Special Features

- Increases Traction
- Durable Glossy Finish
- Easy to Apply
- Barefoot & Paw Friendly
- Chemical Resistant

Suggested Use

- Fiberglass Bathtubs
- Fiberglass Showers
- Hotel Bathrooms
- Residential and Commercial Use

Product Characteristics and Benefits

Surfaces	Fiberglass bathtubs and showers
Color	Milky White Liquid that dries to clear glossy finish
Container Size	1 fl oz bottle. Available in one bottle and two bottle kits
Product Type	Epoxy/acrylic coating
Coverage	One Bottle: one standard bathtub/shower Two Bottle: two standard tubs/showers or oversize tub/shower
Mode of Application	Foam Roller (included)
Dry Time	Recoat: 20 minutes General Use: 12-24 hours
Water Resistant	Yes
Storage	Store at room temp. PROTECT FROM FREEZING.
Shelf Life	2 years unopened; 1 year opened
Warranty	2 years
Removal	Lacquer Thinner or acetone and a plastic scraper
Disposal	Dispose of container and unused contents in accordance with local, state, and federal regulations



Precautions & Technical Support

Please refer to Safety Data Sheet (SDS) for detailed Precautions and First Aid Instructions. Tub Grip Safety Data Sheet can be found at www.slipdoctors.com

Technical Support:

Please contact SlipDoctors at support@slipdoctors.com



TUB GRIP

TECHNICAL DATA SHEET

Directions for Preparation, Application and Use

Read entire product label, Technical Data Sheet (TDS) & Safety Data Sheet (SDS) before using.

Safety Precautions	<ul style="list-style-type: none"> Gloves may be worn when handling Tub Grip. KEEP OUT OF REACH OF CHILDREN.
Surface Preparation	<ul style="list-style-type: none"> For best results, we recommend lightly sanding the surface with 220 grit sandpaper prior to application. Surface must be thoroughly cleaned and allowed to dry prior to application. Bathtubs and showers are ready for coating after the above procedures are complete.
Application Instructions	<ul style="list-style-type: none"> Tub Grip should not be diluted or thinned in any way. Shake Tub Grip bottle for 5-10 seconds. Pour enough contents from the bottle for one thin coat. Use the included foam roller to spread Tub Grip evenly over the surface. Wait 20 minutes, and then apply a thin second coat. If thicker coats are desired and/or if tub/shower is oversized, additional bottles may be needed. Wait 12-24 hours before use to allow Tub Grip to cure completely. CLEAN UP: Wash hands with soap and water after application. Dispose of roller and other package contents. <p>NOTE: If product arrives frozen or clumpy, do not use and contact support@slipdoctors.com for a replacement. Please include your order number if possible.</p>
Maintenance	<p>Clean surface with a SlipDoctors Citrus Clean. Some non-abrasive cleanser, water, and a sponge may work. Avoid using abrasive cleansers and cleaners that contain alcohol or acid.</p>

Warranty & Disclaimer

WARRANTY: All properly installed SlipDoctors products are guaranteed to increase the coefficient of friction of your surface for two (2) years (provided surface preparation and cleaning procedures are followed and no contaminants are present). If at any time during the warranty period the treated surface should lose its coefficient of friction, SlipDoctors shall at its option replace any product that proves defective. This warranty applies only to the product itself. Neither the Seller nor the Manufacturer shall be liable for any injury, loss or damage direct or consequential, arising out of the use or the inability to use the product. Before using, Buyer shall determine the suitability of the product for the intended use, and the Buyer assumes all risk and liability whatsoever in connection therewith. No statement or recommendation not contained herein shall have any force or effect unless in an agreement signed by Seller and Buyer. Buyer assumes all risks and responsibility associated with disposal. SlipDoctors cannot eliminate all possibilities of slip-and-fall accidents. Please visit www.slipdoctors.com to find further warranty information. KEEP OUT OF REACH OF CHILDREN.

